
Instructions for use

HOME DELUXE
WIR MACHEN DEIN ZUHAUSE

LUNA floor lamp



Original instructions for use

Designed in Germany

IMPORTANT:
KEEP FOR FUTURE REFERENCE.
READ CAREFULLY!

Table of contents

1. General information ... 3
1.1. Product overview ... 3
1.2. General notes ... 3
1.3. Guarantee ... 3
2. Information on the instructions for use ... 4
2.1. Availability of the instructions for use ... 4
2.2. Target groups of the instructions for use ... 4
2.3. Information on the translation ... 4
2.4. Explanation of symbols ... 4
2.5. General information on the instructions for use ... 6
2.6. Intended use ... 6
2.7. General safety instructions ... 6
3. Product features ... 8
3.1. Technical data ... 8
3.2. Product description ... 8
4. Scope of delivery ... 9
5. Assembly ... 9
5.1. Safety instructions ... 9
5.2. Structure of the product ... 10
6. Application ... 11
6.1. Safety instructions ... 11
6.2. Initial commissioning ... 11
6.3. Operation ... 11
6.4. Storage location ... 11
7. Troubleshooting ... 12
8. Maintenance and care ... 12
8.1. Safety instructions ... 12
9. Dismantling ... 12

9.1. Safety instructions 12
10. Waste disposal 13
10.1. General information 13
Electrical and electronic equipment - Information for private households 14

Dear customer,

Thank you for choosing a product from **Home Deluxe GmbH**. We hope you enjoy your new LUNA floor lamp.

The instructions for use support you in the installation, commissioning, operation and maintenance of the product. The instructions for use and the safety instructions must be read carefully and in full. Observe these instructions to avoid hazards.

1. General information

1.1. Product overview

Model: Floor lamp LUNA | Item ID: 21516 | Variant ID: 51200

1.2. General notes

In order to fulfil our claim, we are constantly improving quality, simplifying installation and operation and adapting the products to customer requirements. Due to these changes, the current version of the instructions for use can be found on our homepage.

The term "product" is used in the instructions for use for the "Luna floor lamp".

1.3. Guarantee

The statutory liability for defects and warranty rights apply from the date of purchase.
Home Deluxe GmbH accepts no liability for damage caused by non-compliance with the instructions for use. Complaints arising from improper installation or use are excluded from the warranty. In the event of defects in the product, please contact our customer service in writing using the contact form on our homepage, stating the product name, serial number and a photo of the type plate:

Home Deluxe GmbH
Schanzeweg 2
32312 Lübbecke
Germany
Tel: +49 (0)5743 6181-0
www.home-deluxe-gmbh.de

If you have any further questions, please contact our customer service team using the contact form.

2. Information on the instructions for use

2.1. Availability of the instructions for use

The instructions for use are part of the product and should be kept complete and in the immediate vicinity of the product.

2.2. Target groups of the instructions for use

The instructions for use must be read and observed by every person involved in one of the following activities or uses:


- Unpacking
- Assembly / Installation
- Commissioning / Operation
- Maintenance / inspection / care
- Troubleshooting / repair
- Waste disposal

2.3. Information on the translation

The original instructions for use were written in German. Any other language available is a translation of the German version.

2.4. Explanation of symbols

Symbol	Explanation of symbols
	**WARNING** The symbol indicates possible dangers that could result in fatal or serious injuries. Before carrying out the corresponding installation or application step, read the corresponding note.
	**INFO** The symbol provides important information and indicates material damage. Observe these before carrying out the corresponding installation or application step in order to understand problems and avoid damage.
	**CE labelling** The symbol declares the conformity of the product with the applicable requirements of the European Community. The current declaration of conformity is available on request from Home Deluxe GmbH.
	**For indoor use only** The symbol indicates that the product may only be used indoors.
	**Read instructions for use** The symbol indicates that the operating instructions must be read carefully before mounting/installing and/or operating the appliance.

	**Disposal of electrical and electronic appliances** Electrical and electronic appliances must not be disposed of with household waste!
	**Warning of electrical voltage** The symbol indicates that you must not come into contact with electrical voltage.
	**Protection class II** The symbol indicates that the equipment has reinforced or double insulation to the level of the rated insulation voltage between active and touchable parts. They usually have no connection to the protective conductor.
	**Alternating current** The symbol indicates that the product is operated with alternating current.
	**Do not look directly into the light** The symbol indicates that you must not look directly into the light.

2.5. General information on the instructions for use

The operating instructions refer to the LUNA floor lamp. It contains important information on installation, operation, maintenance and cleaning. The instructions for use, in particular the safety instructions, must be read carefully before using the product; keep the instructions for use in a safe place. Only use the product as described in these instructions for use to prevent accidental injury or damage. If you pass the LUNA floor lamp on to a third party, these instructions for use must also be handed over.

2.6. Intended use

The product is of high quality, durable and intended or suitable exclusively for private use to a reasonable and customary extent. Furthermore, our product is **not** intended for commercial use. Commercial use is only permitted with the written authorisation of Home Deluxe GmbH.

Only use the product as described in these instructions for use. Any other use is considered improper and may result in damage to property or personal injury. The manufacturer accepts no liability for damage caused by improper or incorrect use.

2.7. General safety instructions

General hazard warnings



- Improper handling can lead to considerable personal injury and damage to property. For this reason, assembly, installation, commissioning, troubleshooting, maintenance and repair work may only be carried out by qualified persons.
- The product can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- **Only** install the product if the scope of delivery is complete and in perfect condition.
- Ensure that all parts are undamaged and correctly installed. There is a risk of injury if they are not installed correctly. Damaged parts can affect safety and function.
- Only place the product on a safe, level and firm surface.
- Do not make any changes to the product .
- The supply connections must not be short-circuited.

Danger for children



- Keep children away from packaging materials. There is a risk of suffocation!
- Keep children away from the product.
- Keep children away from the assembly site while the product is being assembled. The scope of delivery contains small parts that can be swallowed or cause serious injury.
- Children can injure themselves when playing with the product or when pulling up on the product
- Do not place the product directly or in the immediate vicinity of a play area.
- Explain to the children how to use the product correctly and never leave them unsupervised while playing.
- Remove all sharp objects, broken glass or stones from the vicinity of the product. Ensure that children at play are not at risk.
- Explain to the children how to handle the product correctly.
- Make sure that small children do not put small parts in their mouths.

Risk of injury
Improper handling of the product can lead to injuries



- Check the product for visible damage before each use.
- Do not make any design changes to the product. Any modifications must be authorised in writing by the manufacturer and carried out in accordance with the instructions.
- If the product is damaged, it must no longer be used. Damaged parts must be repaired or replaced with original spare parts.
- Ensure that the product is permanently installed securely to avoid injury.
- To avoid the risk of electric shock, all installations and corresponding maintenance work must be carried out by a qualified electrician.
- If the mains cable for the power supply is damaged, take the product out of operation until the mains cable is replaced by the manufacturer, customer service or a qualified electrician.

Risk of damage



- Improper handling of the product can lead to damage.
- Do not open the packaging with sharp objects (e.g. knives, scissors or similar) as this may damage the product. Be careful when opening.
- If you open the packaging carelessly with a knife or other sharp objects, the product may be damaged. Be very careful when opening the packaging.
- Do not climb onto the product as there is a risk of falling and tipping over.
- Do not use the product near sources of heat or naked flames.

3. Product features



3.1. Technical data

Product name	LUNA floor lamp
Diameter	43 cm
Height	165 cm
Lampshade (diameter x height)	10.5 x 22.5 cm
Weight	2.1 kg
Colour	Black/ Gold
Material/fabric	Metal / Polyester
Cable length	1.7 metres
Performance	60 watts
Frequency	50/60 Hz
Tension	220-240 V AC
Protection class	IP20
Protection class	II

4. Scope of delivery

Check the packaging for external damage on delivery. Furthermore, immediately after unpacking, check that the scope of delivery is complete and that the product and all components are in perfect condition. Only assemble the product if the scope of delivery is complete and undamaged.

Components/parts

No.	Description of the	Quantity	Illustration
A.	Foot end	**3**	
B	Metatarsus	**3**	
C	Start of foot	**3**	
D	Lamp base	**1**	
E	Cable holder	**2**	
F	Lampshade	**1**	
G	Fastening	**1**	

5. Assembly

5.1. Safety instructions

All health and safety information must be read.

Risk of injury


Improper handling during installation can lead to injuries



- Please ensure that the parcels are opened at the top. Be very careful when opening the parcels as there are fragile parts and glass in the parcels.
- Immediately after unpacking, check that the scope of delivery is complete and that the product and all parts are in perfect condition.
- **Only** install the product if the scope of delivery is complete and in perfect condition.
- Only place the product on a safe, level and firm surface.
- Assembly errors or damage caused by assembly are excluded from the warranty.

5.2. Structure of the product

The following instructions must be read carefully.

Illustration	Build-up step
	**Step 1:** Tighten the base end **(A),** the centre base **(B)** and the base start **(C)**. Repeat this process until you have connected all the components together and screw them into the lamp base **(D)**. **Step 2:** Now place the lampshade **(F)** on the lamp base **(D)** and tighten the bracket **(G).** **Step 3:** Now screw an E27 light bulb (max. 60W) into the socket and switch on the lamp. **Note:** The light bulb is not included in the scope of delivery.

6. Application

6.1. Safety instructions

The following health and safety information must be read carefully.

Risk of injury
Improper handling during operation can lead to injuries



- Do not use a damaged product.
- Do not make any changes to the product.
- The product is not a children's toy, climbing wall or sports equipment. Children are not permitted to play with the product.
- Operating errors or damage caused by incorrect operation are excluded from the warranty.
- Check the fastening at regular intervals.

6.2. Initial commissioning

Check the product for damage before using it for the first time. The product may only be used if it is undamaged.

6.3. Operation

Check before using the product,

- the proper condition.
- the electrical connection.

6.4. Storage location

- Store the product in a dry room protected from rain and wind.

7. Troubleshooting

If the following faults occur during operation, please check the following fault causes using the following table. If the fault cannot be rectified by the measures listed, take the product out of operation.

Error	Possible cause	Solution
The product wobbles or vibrates	- The product stands on uneven surfaces	- Place the product on a level surface
The product cannot be switched on	- Light bulb burnt out - Cable damaged	- Replace bulbs - Have the cable replaced or repaired by a qualified electrician

If another problem occurs with the product, please contact us.

8. Maintenance and care

8.1. Safety instructions

Risk of injury
Improper handling during operation can lead to injuries



- Switch off the power supply to the product before cleaning/maintenance/care.
- Clean the surfaces with a damp cloth and a mild detergent. Do not use aggressive cleaning agents or high-pressure cleaners for cleaning.
- Also observe the instructions of the detergent manufacturer.

9. Dismantling

9.1. Safety instructions

Risk of injury
Improper handling during disassembly can lead to injuries



- Disconnect the product from the power supply before dismantling. Contact with live components can result in an electric shock, which can cause burns or death.

Disassembly of the product must be carried out in reverse order to assembly. (**see chapter Assembly**)

10. Waste disposal

10.1. General information

- Dispose of the product and all components in accordance with local and country-specific regulations to prevent damage to the environment.
- Our packaging is made from environmentally friendly materials. They can be recycled and thus serve as valuable raw materials. Dispose of the packaging material (cardboard, dirty packaging, etc.) separately and professionally in accordance with the applicable national regulations.
- Contact the manufacturer if you are unsure about disposal.
- You can also obtain information on proper disposal from the local waste disposal centres

Electrical and electronic equipment - Information for private households

The Electrical and Electronic Equipment Act (ElektroG) contains a large number of requirements for the handling of electrical and electronic equipment. The most important ones are summarised here.

1. Separate collection of old appliances

Electrical and electronic appliances that have become waste are referred to as old appliances. Owners of old appliances must dispose of them separately from unsorted municipal waste. They must separate used batteries and accumulators that are not enclosed in the old appliance, as well as lamps that can be removed from the old appliance without destroying them, from the old appliance without destroying them before handing them in at a collection point. Separate old appliances in order to prepare them for reuse.

2. Batteries and rechargeable batteries



As a rule, owners of waste appliances must separate waste batteries and accumulators that are not enclosed by the waste appliance before handing them in at a collection point. This does not apply if the waste equipment is handed in to public waste management authorities and separated there from other waste equipment for the purpose of preparing it for reuse.

3. Options for returning old appliances

Owners of old appliances from private households can hand them in at the collection points of the public waste disposal authorities or at the take-back centres set up by manufacturers or distributors in accordance with the ElektroG. An online list of collection and take-back centres can be found on the website: https://www.stiftung-ear.de or https://www.take-e-back.de.

4. Data protection notice

Old devices often contain sensitive personal data. This applies in particular to information and telecommunications technology devices such as computers and smartphones. In your own interest, please note that each end user is responsible for deleting the data on the old devices to be disposed of.

5. Take-back obligation of distributors

Distributors with a sales area for electrical and electronic equipment of at least 400 m^2 and distributors of foodstuffs with a total sales area of at least 800 m^2 who offer electrical and electronic equipment and make it available on the market several times per calendar year or on a permanent basis are obliged to fulfil this obligation,

- when supplying a new electrical or electronic appliance to an end user, to take back free of charge at the place of supply or in the immediate vicinity an old appliance of the end user of the same type that essentially fulfils the same functions as the new appliance, and
- at the request of the end user, to take back waste electrical and electronic equipment that does not exceed 25 cm in any external dimension free of charge in the retail shop or in the immediate vicinity; the take-back may not be linked to the purchase of an electrical or electronic appliance and is limited to three old appliances per type of appliance.

6. Meaning of the "crossed-out wheelie bin" symbol



The symbol of a crossed-out dustbin regularly shown on electrical and electronic appliances indicates that the appliance in question must be collected separately from unsorted municipal waste at the end of its service life.

- Manufacturer registration number
- We are registered as a manufacturer within the meaning of the ElektroG with the responsible foundation Elektro-Altgeräte Register (Nordostpark 72, 90411 Nuremberg) under the following registration number: WEEE-Reg. No. DE86467979

Home Deluxe GmbH
Schanzeweg 2
32312 Lübbecke
Germany
Tel: +49 (0)5743 6181-0
www.home-deluxe-gmbh.de

GA-163-00-LUNA
2023/10